



CABLE TRACER PROSKIT MT-7029

The **Proskit MT-7029** is a cable tracer or cable locator tool used to identify and trace wires, cables, or circuits in electrical systems. It is commonly used by electricians, technicians, and network installers to locate and diagnose issues in wiring systems. Below are some key features and details about the Proskit MT-7029:

Key Features of Proskit MT-7029:

1. **Cable Tracing and Identification:**
 - Helps locate and trace wires or cables hidden in walls, underground, or in complex wiring systems.
 - Identifies specific cables in a bundle to avoid confusion during repairs or installations.
2. **Signal Transmission and Detection:**
 - Comes with a transmitter and receiver.
 - The transmitter sends a signal through the cable, and the receiver detects the signal to locate the cable.
3. **Tone Generation:**
 - Generates an audible tone to help identify the correct cable or wire.
4. **Voltage Detection:**
 - Some models may include non-contact voltage detection for added safety.
5. **Portable and Lightweight:**
 - Compact design for easy portability and use in tight spaces.
6. **Adjustable Sensitivity:**
 - Allows users to adjust the sensitivity of the receiver for more accurate detection.
7. **LED Indicators:**

CABLE TRACER PROSKIT MT-7029

- Visual indicators (LEDs) on the receiver help identify signal strength and cable location.
8. **Versatility:**
- Can be used for various applications, including electrical wiring, network cables, and telephone lines.
-

Typical Applications:

- Locating breakers or fuses in electrical panels.
 - Tracing wires in walls, ceilings, or underground.
 - Identifying specific cables in a bundle.
 - Diagnosing wiring issues in electrical or network systems.
-

How to Use the Proskit MT-7029:

1. **Connect the Transmitter:**
 - Attach the transmitter to the cable or wire you want to trace.
 - Ensure the circuit is de-energized (if required) for safety.
 2. **Turn on the Receiver:**
 - Power on the receiver and adjust the sensitivity as needed.
 3. **Trace the Cable:**
 - Move the receiver along the path of the cable while listening for the tone or observing the LED indicators.
 4. **Identify the Cable:**
 - The receiver will indicate when it detects the signal from the transmitter, helping you locate the cable.
-

CABLE TRACER PROSKIT MT-7029

Safety Tips:

- Always ensure the circuit is de-energized before connecting the transmitter (unless the device is rated for live circuits).
- Follow the manufacturer's instructions for proper use.
- Wear appropriate personal protective equipment (PPE) when working with electrical systems.

