



DOLPHIN SWITCHER:

4 way + Remote Control
8 way + Remote Control
12 way + Remote Control
16 way + Remote Control

User manual:

1. Connect the plug into AC socket and switch the **POWER** button on.
2. The device will automatically switch between audio/video channels during a specific time adjusted by the **TIME** variable.
NOTE: if the time is varied the effect won't occur until the next action.
3. To freeze a certain audio/video channel, simply press the button of channels number. Ex: Ch1, Ch2, etc.
4. To return to automatic switching press **AUTO** button.
5. To program the device to skip a certain channel while switching. Press **PROGRAM** button. A 'pr' symbol is displayed, then press any channel number , an 'A0, A1 ...AF ' is displayed.
A=automatic; 1,2,3...F=channel number.
if the same switch is pressed again 'b0, b1' is displayed b=Bypass; 1, 2, 3, ...=channel number. Once specified to bypass mode then the device want switch to this channel unless repressed to automatic mode"A0,A1...".
To end program mode press PROGRAM button again A 'pr' symbol is displayed
6. 6. To memorize the slipped channels press **MEMORY** button at the back of the device. A 'rY' symbol is displayed



Made in Taiwan