



Function controls :

- Digital key pad.
- Program button.
- Panic button.
- Chime on/off switch.
- AC adaptor jack.
- Arm/disarm button.
- Battery low/program indicator.
- Magnetic sensor.
- Extended siren cable.
- Outdoor siren.

Entry Alarm With Digital Security Code & Outdoor Siren (525SK)

Detects entry... Turns on alarm or chime.

- High output 120dB outdoor siren.
- Easy installation.
- Magnetic sensors detects entry & activates alarm.
- Built-in indoor alarm.
- Panic button.
- AC Adaptor included.

Made in Hong Kong