

Earth tester

Model: MS5209



Features:

- Measuring earth resistance by constant current inverter 800Hz approx 2mA, earth voltage by rectifier type 5k Ω /V approx 40~500Hz
- Large, easy to read scale
- No external power supply required, always ready for use on site
- Self-check facility

Specifications:

Factor	Range	Accuracy
Earth resistance	10/100/1000 Ω	$\pm 5.0\%f.s.$
Earth voltage	30V AC, 5k Ω /V	$\pm 5.0\%f.s.$
Dimensions	140x140x90mm	
Battery	1.5Vx8 AA size	